Turf Tips for installing Grassmats

Growing from Seed:

Prepare the area that you want to lay Grassmats over, by leveling and smoothing out the surface as best as possible, according to your budget. Remove rocks, stones and sharp objects where possible. Rake the area over and sow your seed. Cover as directed with thin layer of soil and if possible a thin layer of sand.

Lay Grassmats directly over the area, pin and zip tie them as needed.

Water/ irrigate the seeded area to allow the seed to germinate. Do not let the area dry out or you may loose the new growth, but don't over water. In favorable conditions seed should germinate in 10 to 14 days.

Laying Sod:

Prepare the surface as above for new sod. Lay as needed for the area to be covered. Please allow a couple of weeks for the sod to take, with watering/ irrigation before laying Grassmats to avoid to much stress on the grass before it can take.

Time for the sod to take will vary depending on grass type, the ambient air and soil temperatures.

Further information:

Please be mindful when selecting grass types, of sunlight, shaded areas, where you are geographically as far as a warm season or cool season tolerant grass type.

Mowing:

Grassmats can be mowed as normal once the grass has grown through the holes in the mat. Cut around 1" to 2"s for best results.

Note: the leading edges of the mat need to be protected, by burying or backfilling up to the edge to avoid the mowers catching the leading edge.

For more help or information please contact:

grassmatsusa@gmail.com

864 276 5557